


ER-380 Replacement Parts



Ref. No.	CRS Item No.	Description
01	102121	Cover, Printer ER-380/390M
02	300537	Samsung Control Lock
03	102000	Upper Case Samsung ER-350/380
04	501327	Printer Assy STM-210
05	501355	Logic Board ER-380
06	500987	Keyboard Assy ER-380M N/S
07	501405	Logic Board Assy ER-380M
08	160257	Drawer Model 57 ECR Ivory 24V
09	102004	Turret Window ER-350

Ref. No.	CRS Item No.	Description
10	501342	Display Rear 380,5115li,5200
11	102003	Turret Body ER-350
12	501021	Front Display Assy ER-350/380
13	102008	Spool ER-290,350,380,550
14	202987	Transformr 650/52/52M/650R/70
16	200080	Power Cord SER-6500/6540
17	501357	Motor Assy ER-380
18	102123	Mode Cover ER-380